

# Operating Instructions

---

## Electric On/Off Control Operation Option

### *Check Gas Supply is turned on*

#### **To Start**

Make sure the room switch is in the *off position* and the pilot light is lit according to your manual system.

Set your manual control to the high flame setting.

The room switch may now be used to turn the fire on and off as desired.

When the room switch is in the off position the pilot will remain alight.

#### **NOTE:**

If the gas line has been interrupted when first lighting the fire, it may be necessary to follow the start up sequence several times.

#### **High / Low Flame**

Turn the control knob to light the main burner.

Small Flame Diagram is low.

Large Flame Diagram is high or anywhere in between as desired

#### **Shut Off**

Turn the control knob clockwise to either the pilot position so that only the pilot remains alight or to the off position to extinguish the pilot light.

#### **Safety Shut Off**

The variable rotary control will automatically shut down should the pilot be interrupted or the pilot fails to light.

#### **NOTE:**

If the system fails to light after several attempts, call for a registered Living Flame Maintenance Engineer or Living Flame Auckland for your nearest Registered Service Agent.

---

DISPLAY CENTRE: 343b Church Street, Penrose, Auckland  
TELEPHONE: 64 9 622 1148  
FAX: 64 9 622 1179  
EMAIL: [info@livingflame.co.nz](mailto:info@livingflame.co.nz)  
WEB: [www.livingflame.co.nz](http://www.livingflame.co.nz)