

Operating Instructions

Manual Two Stage Two Button Control

Check Gas Supply is turned on

To Light the Pilot (right hand button)

Push in the right hand button with the sparker diagram on it and hold in for approximately 10 – 20 seconds (this will allow the gas to flow through).

Light the Pilot with a Gas Lighter/Match.

DO NOT USE A CANDLE TO LIGHT THE PILOT LIGHT.

Once the pilot has lit, continue to keep the right hand button depressed for 30seconds.

Release the button and the pilot should stay alight.

NOTE:

If the gas line has been interrupted when first lighting the fire, it may be necessary to follow the start up sequence several times.

To Light the Main Burner

The pilot should be alight.

The right hand button now becomes the on / off.

On = push the button so that it pops out.

Off= depress the button in.

High / Low Flame (left hand button)

Low = The left hand button depressed in

High= The left hand button is out



NOTE:

When lighting the burner for the first time in the day make sure the high/low button is popped out. This will help the main burner to light quickly and smoothly.

Shut Off

Depress the on / off right hand button so only the pilot remains alight. (recommended for ease of ignition, will use a minimal amount of gas)

Safety Shut Off

If the pilot is extinguished for any reason the valve will automatically shut off the gas supply as your fire is fitted with a flame failure heat sensor.

DISPLAY CENTRE: 343b Church Street, Penrose, Auckland

TELEPHONE: 64 9 622 1148

FAX: 64 9 622 1179

EMAIL: info@livingflame.co.nz

WEB: www.livingflame.co.nz