

Customer Operating Instructions

TWO STAGE TWO BUTTON CONTROL

To Light the Pilot ('Star' button):

- Confirm that the gas supply is turned on.
- Push in the 'Star' button and hold for 10-20 seconds to allow gas flow.
- Light the pilot with a gas lighter / match. **DO NOT USE A CANDLE TO LIGHT THE PILOT LIGHT.**
- Keep the button depressed for 30 seconds after the pilot lights.
- Release the 'Star' button and the pilot should stay alight.
- **Note:** In case of an interruption in the gas line during the initial ignition, it may be necessary to repeat the start-up sequence multiple times.

To Start the Fire:

- The pilot should be alight.
- The 'Star' button now becomes the On / Off.
- On - Push the 'Star' button so that it pops out. A large flame icon will be displayed in the corresponding window.
- Off - Depress the 'Star' button. A star icon will be displayed in the corresponding window.

The High / Low Flame ('Flame' button):

- Low - Depress the 'Flame' button. A small flame icon will be displayed in the corresponding window.
- High - Push the 'Flame' button so that it pops out. A large flame icon will be displayed in the corresponding window.
- **Note:** When lighting the burner for the first time in the day, make sure the 'Flame' button is popped out. This will help the main burner to light quickly and smoothly.

To Turn the Fire Off:

- To shut off, depress the 'Star' button to keep only the pilot alight (recommended for ease of ignition and minimal gas usage).

The Safety Shut-Off:

- If the pilot is interrupted or fails to ignite, the Two Stage Two Button control will automatically shut down.
- During the summer, you have the option to extinguish the pilot light, and the valve will automatically close for safety.



- **Note:** Your fireplace should be serviced annually by Living Flame or a registered service agent.